

MJR-7000EZ Time Equipment Corp 718.441.8000

Setting the time and turning off daylight saving time change

1. Place key in the top lock and turn - the display will go blank
2. Press **1 E E**
3. Enter time as hour and minute in 24 hour format e.g. 8:05**am** is 0805 3:27**pm** is 1527 and then **press E**
4. Press **2 E E 1 E E**
5. Turn the key back and remove.