



TIME EQUIPMENT CORP.

131-16 101st Avenue, Richmond Hill, NY 11419

(718)441-8000 Fax (718)441-8292

www.timeequipment.net

TIME CHANGE / DAYLIGHT SAVING INSTRUCTIONS FOR MJR7000 AND MJR8000

1. Place key in the top lock and turn - the display will go blank. We need to ensure that your model is not an MJR7000EZ. The instructions are as follows:
2. Press 1.
3. If the display shows 2009, you have an MJR7000EZ. Turn the key back to normal. Please go to our website and download the instructions for the MJR7000EZ. Do NOT proceed with the instructions below.
4. If the display is blank then you have an MJR7000 proceed to step 5.
5. If the time is correct go to step #10 to set only the daylight savings information.
6. Press **1 0 E**
7. Enter the year and then **press #**
8. Enter the month and date and then **press #**
9. Enter time as hour and minute in 24 hour format e.g. 8:05am is 0805 3:27pm is 1527 and then **press E**
10. Press **2 0 E 0311 # 1104 E**
11. Press **I** - this is the top left button, **NOT** the number 1.
12. Turn the key back and remove.